

## **The patented Boat Vent II**

**installs quickly and easily,  
with no screws or fasteners.**

**For use with 3/4" and 7/8" Support Poles**  
(not included)

**#11982**

### **Easy Step-by-Step Installation:**

1. Cut or punch a 2 1/4" hole-use this card as a template.
2. Unscrew nut, slide off lower washer.
3. Put lower washer flange up thru hole.
4. Push cap down thru hole, thru lower washer.
5. Screw nut on tightly.
6. Push pole into coupler and adjust height.



Use this template to  
make hole in cover



Taylor Made Products

[www.taylormadeproducts.com](http://www.taylormadeproducts.com)

A Member of The Taylor Made Group

Gloversville, NY 12078