



DOCKPRO Dock Cushion Installation Instructions

#46011

Hybrid construction means soft compressible foam where you want it and tough high density foam where you need it. The inner core of the new foam bumper is a lower density EVA foam (2.8 pounds per cubic foot) and the outer (front and back) pieces are tougher, higher density PE foam (8.7 pcf).

Instructions:

- 1) Position the dock bumper into its mounting location and mark the 4 mounting hole locations with a pencil.*
- 2) Drill the mounting holes with a 5/16" drill bit.*
- 3) Using four 1/4" diameter bolts secure the bumper (for mounting to 2" thick lumber a 2.75" long bolt is recommended).*
- 4) Secure the bolts with washers and lock nuts on the back side.*



Foam plugs are supplied to give the bumper a clean, finished look.

Taylor Made Products

65 Harrison St., Gloversville, NY 12078

www.taylormadeproducts.com

Made in China

A Member of The Taylor Made Group

© 2017 Taylor Made Group, LLC