



**Taylor Made**  
PRODUCTS™

**Boat Guard**®  
**RainBreaker**™  
Boat Cover

**Installation Instructions**

**BoatGuard® Rainbreaker™ Boat Covers are not intended for trailering applications: DO NOT TRAILER YOUR BOAT WITH A RAINBREAKER COVER IN PLACE.**

**Installing your cover:**

1. Carefully unpack your cover, keeping cover free of dirt and other contaminants in case you need to return the cover for a different size.
2. Place cover over your boat; easiest way is for two people to unfold the cover while draping it over the boat from bow to stern.
3. Once placed over the entire boat be sure the cover you have chosen is the correct size for your boat. The cover should be large enough to cover the boat down to the rub-rail all around the boat.
4. The bow of the cover has an opening that allows the shock-cord to be tightened. Simply pull the cord from both directions in the hem; tie off and remove excess. The amount of tightening depends on the fit of the cover to your boat and your preference. Increased tightening will insure that the cover fits snugly against the hull and is used in mooring applications. A looser adjustment is sometimes preferred in a storage application.
5. Heavy duty tie down cord is included with the cover. Use this to secure the cover to your trailer at each of the webbing tie-down loops sewn into the hem.

**USE AND CARE**

**Before covering your boat.**

1. Remove or firmly tie down detachable accessories, such as auxiliary motors, ladders, spotlights, navigation lights, ski brackets, etc.
2. Pad sharp edges, corners, or projections. the easiest way is to wrap old towels or pieces of carpeting over and around protrusions. If necessary these pads can be taped firmly in place.

**Tying Down the cover.**

The snugness of the cover is the single most important factor for insuring troublefree boat cover life. Each and every tie down loop must be securely tied to either the boat or trailer using rope, shock cord, or straps. (NOTE: If tying off to the trailer, the boat MUST be rigidly fastened to the trailer.) Before tightening, the cover must be properly supported and padded. Protect the sides of your boat from hooks or buckles that may scratch the finish.

**Supporting the cover.**

Large open areas such as cockpits and open bows require support to keep the cover from sagging and allowing water, snow, or ice to pocket. Use boat cover support poles, bows or slats, or other apparatus to create a "tenting" effect and eliminate pockets from forming.

**Cleaning the cover.**

Wash boat covers with mild soaps. Use a garden hose to rinse dirt off. Never use harsh chemical cleaners or solvents on your cover.

**Taylor Made Products**

65 Harrison Street  
Gloversville, NY 12078  
Made in China  
A Member of The Taylor Made Group  
www.taylormadeproducts.com

**CAUTION: BE SURE TO PROTECT THIS PRODUCT FROM DAMAGE WHEN HANDLING . . . . .**

This cover has been manufactured and inspected in accordance with our strict quality standards. We are confident that you will be satisfied with your new boat cover; however, Please follow these guidelines:

- Be sure that your boat is clean and dry prior to trying the cover on.
- Take care when pulling the cover over potentially sharp areas, such as corners of windshield.
- Should you have any problems, carefully remove and re-box the cover immediately - to ensure that the product is not soiled or exposed to the elements.
- Contact your place of purchase within (7) days for exchange or refund.

**ONE YEAR LIMITED WARRANTY**

Taylor Made Products warrants its poly/cotton, semi custom, and custom boat covers to be free from defects in workmanship and material.

Under the terms of this warranty, any Taylor Made Products' Boat Cover found defective within 12 months from the date of purchase, will be repaired or replaced, at Taylor Made Products' option, at no charge.

All Boat Covers must be returned to Taylor Made Products to qualify for warranty. **DO NOT RETURN PRODUCTS TO YOUR DEALER.** Proof of purchase must be included. Transportation charges to Taylor Made Products are the responsibility of the customer. Before returning defective product, please call 1-800-628-5188 for a return authorization number.

This warranty does not cover damage caused by trailering, improper use, accidents, or acts of nature. Covers that are allowed to pocket water or ice, come into contact with chemicals or tree sap, or Boat Covers that are not properly tied down or supported are not covered under this warranty.

TAYLOR MAKES NO EXPRESS OR IMPLIED WARRANTIES OTHER THAN WARRANTIES SET FORTH HEREIN, INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR FROM ANY COURSE OF DEALING OR TRADE USAGE.

TAYLOR SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF OPPORTUNITY OR BUSINESS PROFITS, BUSINESS INTERRUPTION OR ANY OTHER LOSS EVEN IF TAYLOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

IN NO EVENT SHALL TAYLOR BE LIABLE FOR ANY AMOUNT IN EXCESS OF THE PURCHASE PRICE PAID.